



WARNING!
 THE CONNECTOR OF THE GAS INJECTOR A MUST CORRESPOND TO THE BLUE WIRE OF THE PETROL CUT-INJECTOR. THE WIRES TO INTERRUPT ARE INJECTORS NEGATIVE WIRES.

DI60

